


Capacitor Bank Junction Box Assy To Oil Switch To Oil **Switches** CP-0122-PNC Junction Box CP-0125-PNC Transformer Cable CP-0120-PNC 6-Jaw Meter Base CP-0121-PNC CP-0124-PNC Lindsey Sensor Cable Meter Base Cable

CP-0135-PNC

Cross Arm Mount consisting of: CP-0122 6-Ciruit Junction Box CP-0120 6-Jaw Meter Base CP-0124 Meter Base Cable CP-0125 Transformer Cable CP-0121 Lindsey Sensor Cable

Capacitor Bank Junction Box Assy



CP-0123-PNC


Cross Arm Mount consisting of: CP-0122 6-Ciruit Junction Box CP-0120 6-Jaw Meter Base CP-0124 Meter Base Cable CP-0125 Transformer Cable

Note: 1. All junction box assemblies are weather-resistant.






Capacitor Bank Junction Box Assy



CP-0189-PNC

Cross Arm Mount consisting of: CP-0122 6-Ciruit Junction Box CP-0187 6-Jaw Meter Base CP-0124 Meter Base Cable CP-0125 Transformer Cable CP-0121 Lindsey Sensor Cable

Capacitor Bank Junction Box Assy



CP-0267-PNC


Cross Arm Mount consisting of: CP-0277 8-Ciruit Junction Box CP-0120 6-Jaw Meter Base CP-0124 Meter Base Cable CP-0125 Transformer Cable

Note: 1. All junction box assemblies are weather-resistant.





Capacitor Bank Junction Box Assy



CP-0242-PINC


Cross Arm Mount consisting of: CP-0253 8-Ciruit Junction Box CP-0124 Meter Base Cable CP-0125 Transformer Cable CP-1269 Neutral Sensor Cable

Capacitor Bank Junction Box Assy J63 Configuration Lindsey Sensor Cable To Oil CP-0209-LS-J63-PNC Switch To Oil Switches CP-0212-PNC Junction Box То Transformer Cross Arm Mount consisting of: CP-0187-PNC 6-Jaw Meter Base CP-0212 6-Ciruit Junction Box CP-0187 6-Jaw Meter Base, J63 CP-0124 Meter Base Cable CP-0124-PNC CP-1157-PNC Lindsey Sensor Cable CP-1157 Lindsey Sensor Cable Meter Base Cable

Note: 1. All junction box assemblies are weather-resistant.







Lindsey Sensor Cable

CP-0209-LS-J61-PNC

Cross Arm Mount consisting of: CP-0212 6-Ciruit Junction Box CP-0210 6-Jaw Meter Base, J61 CP-0124 Meter Base Cable CP-1157 Lindsey Sensor Cable

Capacitor Bank Junction Box Assy J62 Configuration **Lindsey Sensor Cable** To Oil CP-0209-LS-J62-PNC To Oil Switch **Switches** CP-0212-PNC Junction Box Transformer CP-0120-PNC 6-Jaw Meter Base CP-0124-PNC CP-1157-PNC Meter Base Cable Lindsey Sensor Cable


Cross Arm Mount consisting of: CP-0212 6-Ciruit Junction Box CP-0120 6-Jaw Meter Base, J62 CP-0124 Meter Base Cable CP-1157 Lindsey Sensor Cable

Note: 1. All junction box assemblies are weather-resistant.





Junction Boxes



CP-0209-FP-J61-PNC

Cross Arm Mount consisting of: CP-0212 6-Ciruit Junction Box CP-0210 6-Jaw Meter Base, J61 CP-0124 Meter Base Cable CP-0145 Fisher-Pierce Sensor Cable

Capacitor Bank Junction Box Assy J62 Configuration Fisher-Pierce Sensor Cable To Oil To Oil Switch **Switches** CP-0212-PNC Junction Box То Transformer CP-0120-PNC Cross Arm Mount consisting of: 6-Jaw Meter Base CP-0124-PNC CP-0145 Meter Base Cable Fisher-Pierce Sensor Cable

CP-0209-FP-J62-PNC


CP-0212 6-Ciruit Junction Box CP-0120 6-Jaw Meter Base, J62 CP-0124 Meter Base Cable CP-0145 Fisher-Pierce Sensor Cable

Note: 1. All junction box assemblies are weather-resistant.






Capacitor Bank Junction Box Assy Lindsey Sensor Cable



CP-0208-LS-PNC

Cross Arm Mount consisting of: CP-0211 6-Ciruit Junction Box CP-1157 Lindsey Sensor Cable

Capacitor Bank Junction Box Assy Fisher-Pierce Sensor Cable




CP-0208-FP-PNC

Cross Arm Mount consisting of: CP-0211 6-Ciruit Junction Box CP-0145 Fisher-Pierce Sensor Cable

Note: 1. All junction box assemblies are weather-resistant.








CP-0144-PNC

Pole Mount consisting of: CP-0143 6-Ciruit Junction Box CP-0153 6-Jaw Meter Base

Capacitor Bank Junction Box Assy




CP-0220-PNC

Rack Mount consisting of: CP-0222 6-Ciruit Junction Box CP-0113 6-Jaw Meter Base, J63 CP-2030 Meter Base Cable CP-1231 Lindsey Sensor Cable

Note: 1. All junction box assemblies are weather-resistant.








CP-0280-PNC

Rack Mount consisting of: CP-0281 6-Ciruit Junction Box CP-0113 6-Jaw Meter Base CP-2030 Meter Base Cable CP-1072 Transformer Cable

Capacitor Bank Junction Box Assy



CP-0278-PNC


Rack Mount consisting of: CP-0279 6-Ciruit Junction Box CP-0225 4-Jaw Meter Base CP-2037 Meter Base Cable


Note: 1. All junction box assemblies are weather-resistant.





Junction Boxes






Note: 1. All junction box assemblies are weather-resistant.





Capacitor Bank Junction Box Assy J40 Configuration w/ Oil Switch Cables



CP-0217-PNC

Cross arm mount for J40 configuration. Supplied with an 8-circuit terminal strip, oil switch cables, transformer cable, meter cable, and a knock-out for sensor cable.

Note: 1. All junction box assemblies are weather-resistant.






Capacitor Bank Junction Box Assy w/ Oil Switch Cables

CP-0122-PNC



Cross arm mount. Supplied with a 6-circuit terminal strip and oil switch cables. Includes Mil-Spec connectors for sensor cable and meter base.

Capacitor Bank Junction Box Assy w/ Oil Switch Cables



CP-0277-PNC

Cross arm mount. Supplied with a 8-circuit terminal strip, oil switch cables, and Mil-Spec connectors for sensor cable and meter base.


Note: 1. All junction box assemblies are weather-resistant.





Capacitor Bank Junction Box Assy w/ Oil Switch Cables

CP-0253-PNC



Cross arm mount. Supplied with a 8-circuit terminal strip, oil switch cables, and Mil-Spec connectors for sensor cable and meter base.

Capacitor Bank Junction Box Assy w/ Oil Switch & Transformer Cables

CP-0212-PNC



Cross arm mount. Supplied with a 6-circuit terminal strip, oil switch cables, and transformer cable. Includes Mil-Spec connectors for sensor cable and meter base.

Note: 1. All junction box assemblies are weather-resistant.






Capacitor Bank Junction Box Assy w/ Oil Switch & Transformer Cables

CP-0211-PNC



Cross arm mount. Supplied with a 6-circuit terminal strip, oil switch cables, transformer cable. Includes Mil-Spec connectors for sensor cable and meter base.

Capacitor Bank Junction Box Assy w/ Oil Switch & Power Source Cables



CP-0143-PNC

Pole mount. Supplied with a 6-circuit terminal strip, oil switch cables and 120 VAC power source cable. Includes CGB for meter base and a Mil-Spec connector for sensor cable.

Note: 1. All junction box assemblies are weather-resistant.





Capacitor Bank Junction Box Assy w/ Oil Switch & Transformer Cables



CP-0222-PNC

Rack mount. Supplied with a 6-circuit terminal strip, oi switch cables, and transformer cable. Includes CGB's for sensor or meter cables.

Capacitor Bank Junction Box Assy w/ Oil Switch & Transformer Cables



CP-0281-PNC

Rack mount. Supplied with a 6-circuit terminal strip, oil switch cables, and transformer cable. Includes CGB's for sensor or meter cables.

Note: 1. All junction box assemblies are weather-resistant.





Junction Boxes

Capacitor Bank Junction Box Assy w/ Oil Switch & Transformer Cables



CP-0268-PNC

16" mounting plate. Supplied with a 6-circuit terminal strip, oil switch cables, and transformer cable. Includes CGB's for meter and sensor cables.

Capacitor Bank Junction Box Assy



CP-0274-PNC

16" mounting plate. Supplied with a 6-circuit terminal strip and CGB's.

Note: 1. All junction box assemblies are weather-resistant.



PELCO PRODUCTS, INC.

Voltage Control Box Assy w/ 8-Circuit Terminal Strip



CP-0148-PNC

Pole mount. Supplied with an 8-circuit terminal strip and CGB's on side and bottom of box.

Recloser Junction Box Assy w/ 8-Circuit Terminal Strip



CP-0214-PNC

Cross arm mount. Supplied with an 8-circuit terminal strip and Mil-Spec connector.

Note: 1. All junction box assemblies are weather-resistant.





Junction Boxes

Capacitor Bank Junction Box Assy VAR Control

CP-0136-PNC



Pole mount. Volt-ampere reactive junction box supplied with a 8-circuit terminal strip, oil switch cable without the connector, a cord grip, and a CGB.

Capacitor Bank Junction Box Assy VAR Control

CP-0216-PNC



Pole mount. Volt-ampere reactive junction box supplied with a 8-circuit terminal strip and watertight CGB's.

Note: 1. All junction box assemblies are weather-resistant.





This page is intentionally left blank.







6-Jaw Meter Base w/ Mounting Bracket, Meter Ring, & CGB w/ 7 Conductor x 25' Cable For J62 Configuration

CP-0138-PNC

6-Jaw Meter Base w/ mounting bracket and ring. Includes a CGB with 12 AWG 7 conductor x 25' cable on the bottom. For J62 wiring configurations.




6-Jaw Meter Base w/Mounting Bracket, Meter Ring, & Mil-Spec Connector For J62 Configuration

CP-0120-PNC

6-Jaw Meter Base w/ mounting bracket and ring. Includes a Mil-Spec connector on the bottom. For J62 wiring configurations.







Perco

CP-0187-PNC

6-Jaw Meter Base w/ mounting bracket and ring. Includes a Mil-Spec connector on the bottom. For J63 wiring configurations.



6-Jaw Meter Base w/ Mounting Bracket, Meter Ring, & Mil-Spec Connector For PHI/MATISS Configuration

CP-0190-PNC

6-Jaw Meter Base w/ mounting bracket and ring. Includes a Mil-Spec connector on the bottom. For PHI/ MATISS wiring configurations.





Meter Base, 6-Jaw w/ Mounting Bracket & Meter Ring, Alum





6-Jaw Meter Base w/ mounting bracket and ring. Includes a 3/4" .45"-.56" wire CGB on the bottom.

Meter Base, 6-Jaw w/ Meter Ring, Alum



CP-0223-PNC

6-Jaw Meter Base w/ mounting bracket and ring. Includes a 3/4" .55"-.65" wire CGB on the bottom.

Note: 1. All assemblies are supplied standard with stainless steel fasteners.











2-conductor 16 AWG cable x 25'-0" long with male and female Mil-Spec connectors. For use with Lindsey Sensor and Junction Box wired for Lindsey or Fisher Pierce Sensors.

Lindsey Sensor Cable w/ Mil-Spec Connectors



CP-0121 - 120=120" 240=240"

2-conductor 16 AWG cable with male and female Mil-Spec connectors and an option of length. For use with Lindsey Sensor and Junction Box wired for Lindsey Sensor only.





Cable Assemblies

Lindsey Sensor Cable w/ Mil-Spec Connectors

CP-0193-PNC



4-conductor 16 AWG cable x 20'-6" long with male Mil-Spec connectors. For use with Lindsey Sensor.

Fisher-Pierce Sensor Cable w/ Mil-Spec Connector

CP-0192-PNC



3-conductor 16 AWG cable x 25' long with male Mil-Spec connector on junction box end. For use with Fisher-Pierce Sensor.



DEC SPANIETS INC.

Transformer Cable w/ Mil-Spec Connector



CP-0125-PNC

2-conductor 12 AWG cable x 10'-6" long with female Mil-Spec connector on junction box end. For use with transformer 120V secondary power supply.

Recloser Box Cable w/ Mil-Spec Connectors



CP-0215-PNC

8-conductor 12 AWG cable x 40'-6" long with male and female Mil-Spec connectors. For connecting reclosure box to meter.





Cable Assemblies

Meter Base Cable w/ Mil-Spec Connectors for J61 & J62 Wiring Configuration





7-conductor 12 AWG cable x 40'-6" long with male and female Mil-Spec connectors. For use with J61 and J62 wiring configuration.

Meter Base Cable w/ Mil-Spec Connectors





7-conductor 12 AWG cable x 35' long with female Mil-Spec connectors both ends and protective cap one end. For connecting junction box to meter.





